MUGEN

CARE AND MAINTENANCE GUIDE

THIS GUIDE COVERS EVERYTHING YOU NEED TO USE, CLEAN AND CARE FOR YOUR MUGEN SOFA, SO IT PERFORMS AT ITS BEST AND LASTS LONGER. WITH PROPER CARE, IT WILL KEEP ITS ORIGINAL LOOK AND FUNCTION OVER TIME.

CONDITIONS OF USE

The sofa is made 100% from high-resilience foam that springs back after every use. We recommend:

-Using it indoors only.
-Avoiding prolonged exposure to direct sunlight.
-Keeping it away from direct heat sources and and excessively humid environments.
-Not jumping on it, placing heavy objects on it or concentrating weight on a single point.

With normal use, the foam may show temporary compression. To help it regain its shape:
-Rotate and rearrange the modules every 2 to 3 months, depending on how much they're used, so the foam recovers evenly.
-Let it rest after long periods of use.

REMOVABLE COVERS

Every surface of the sofa is covered with removable, washable covers. The covers fit snugly over the foam, so removing them and putting them back on takes a little care:
-Open the zippers all the way.
-Gently press the corners of the foam inward to release the fabric.
-Slide the cover off by holding the fabric or its corners, gently.
-To put it back on, reverse the process: press the foam and ease the fabric into place little by little, starting with the corners.

Avoid:

× Pulling on the zippers or seams
× Forcing the fabric

TIP

The fabric comes with a factory spill-resistant treatment that may wear off with washing. To renew it, apply a waterproofing fabric protector spray (we recommend 3M Scotchgard™ Fabric & Upholstery Protector) to the covers once they're dry, following the product's instructions.

MACHINE WASHING

The covers are designed for home machine washing under the following conditions:
-Remove the covers carefully.
-Close all zippers before washing.
-Wash on a short delicate cycle, 15 to 30 minutes.
-Use cold water or a maximum of 40 °C (104 °F).
-Use a neutral or mild detergent.
-Medium spin, 600 to 800 rpm.
-Air dry, laid flat and out of direct sunlight.

Do not use:

× Bleach or whiteners
× Fabric softener
× Tumble dryer
× Iron

Put the covers back on only when they are completely dry.

SPOT CLEANING

If something spills:
-Remove the liquid right away.
-Use a clean, dry cloth.
-Blot gently, without rubbing.

Cleaning right away keeps the liquid from soaking into the fabric's fibers.

For localized stains:
-Apply water and neutral soap with a slightly damp cloth.
-Blot the area without rubbing.
-Remove any residue with a clean, damp cloth.

Do not use:

× Solvents
× Abrasive products
× Industrial detergents or harsh chemicals

Avoid rubbing too hard so you don't damage the fabric's finish.

PROFESSIONAL CLEANING

We recommend having the sofa professionally cleaned at least once a year, or more often depending on how much it's used. Professional cleaning removes built-up dirt and helps the fabric keep its color.
Our fabrics are made to withstand everyday use, but like any high-performance fabric, they last longer with good care.